

Wiring Conversion from VSI to 5500 M Series

VSI Switch
Series 5500
Terminal #

L1 connect to
L2 connect to
P connect to
H1 connect to
H2 connect to

5500 M
Series
Terminal #

L1
L2
P
H1
HC

